


Modified Gilbertson PVC Bluebird Nest Box




Roof

Drip line grooves 1/8" deep,
5/8" in from edge, three sides

23/32" hole X 1 3/4" deep
through wood block, center as
shown, do not penetrate roof
(pole conduit attachment)

Assembly



Wood 1 1/2" X 1 3/4" by 7 1/4" long
(wood block)

#8 X 3/4" self-tapping sheet metal screw,
installed when attaching conduit, into conduit

Attach roof to wood block using
exterior glue and two #8 X 1 1/2" coated
deck screws installed from the topside,
drill pilot holes

Body of screws 4 1/8" apart,
K-Lathe Screws #8 X 1", position
so that PVC box is centered side
to side on roof, screw in screws
until head is 3/8" above surface

Drip line groove 1/8" deep,
5" diameter circle, position
to center on K-Lathe screws,
circle will end up outside
PVC body

Roof - 3/4" PVC (recommended)
or Cedar - 8 1/2" X 7 1/4"

Material List for Roof

- 1 - 8 1/2" X 7 1/4" X 3/4" Cedar or PVC (PVC is recommended) PVC house trim works well (roof)
- 1 - 1 1/2" X 1 3/4" X 7 1/4" Cedar or other wood (a 2X 4 cut in half works well), paint if not cedar (wood block)
- 2 - K-Lathe screws #8 X 1" (for PVC nest body attachment)
- 2 - Coated deck screws #8 X 1 1/2" (attach roof to wood block)
- 1 - Self-tapping sheet metal screw #8 X 3/4" (for pole attachment)
- 1 - Small amount of exterior glue (roof to wood block)
- 1 - Pole assembly

(OVER)

Page 1 of 2